



REAR SPOILER INSTALLATION GUIDE



To install the Maier rear spoiler:

A) Clean the trunk

B) Hold the spoiler up to the trunk

C) Take Masking tape (like the Blue painters tape), outline the edges of the spoiler as it sits, marking YOUR TRUNK with the tape. The idea is that you want a guide fitment... where to put the spoiler when you have the tape exposed. Outline the corners of the spoiler, right & left.

D) Wipe down the trunk locations that the double sided tape will eventually adhere to... with the 3M adhesive promoter/wipe (provided by Maier)

E) Peel the red backing off the tape (on the spoiler, provided by Maier 3M 06383/tape)

F) 2 or 3 people are advisable to do this- one person on each side of the car. **the key is to place it on the trunk ONE TIME. It will NOT reposition easily if at all.

G) Hold the spoiler up against the car for 3 or 4 minutes with some pressure (just by hand)

H) Take off the masking tape

Done-

If you have issues with the fit.. it is OFTEN times not sitting where it needs to be on the trunk. To take it off is not so easy. WD-40 and dental floss is how we have done it before. Call in, if you are having issues.